COOPER Power Tools

Parts Manual • Ersatzteil–Liste

PL30-1004 April 6, 2006

DOTCO®

45-8002

10R04.. & 10N04.. Series
Light Duty Precision Grinders



Model Number	Throttle Type	RPM
10N0400	None	60,000
10N0401	None	60,000
10R0400	Roll	60,000
10R0401	Roll	60,000
10R0402	Roll	40,000
10R0412 *	Roll	60,000

* Note: Wrenchless Chuck model


IMPORTANT: Read and comply with all safety and operating instructions.

For additional product information visit our website at www.cooperpowertools.com

Cooper Power Tools
P.O. Box 1410
Lexington, SC 29071-1410

DOTCO

10-0400 Series Light Duty Precision Grinder



DOTCO
10-0400 Series Light Duty Precision Grinder

Illustration "A" - 10-04 Series Pencil Grinder

Ref.	Number	#	●	Kit	EN	DE	FR	ES	IT
					Description	Benennung	Designation	Description	Descrizione
1	6061	1			Overhose Spring	Druckfeder	Ressort	Resorte	Molla
2	Table A	1			Exhaust Adapter	Zwischenstück	Adaptateur	Adaptador	Adattatore
3	Table A	1			Set Screw	Stellschraube	Vis de pression	Tornillo fijador	Vite di arresto
4	6050	2			O-Ring	O-Ring	Joint torique	Anillo “O”	Anello ad O
5	01-0935	1			Roll Valve	Ventil	Soupape	Válvula	Valvola
6	01-0929	1			Valve Body	Ventilkörper	Corps de soupape	Cuerpo de válvula	Corpo della valvola
7	954	1			Pin	Stift	Goupille cylindrique	Pasador	Spina
8	950	1			Air Inlet Adapter	Zwischenstück	Adaptateur	Adaptador	Adattatore
9	948	1			Inlet Tube	Rohrmutter	Tube	Tubo	Tubo
10	Table A	1			Housing	Gehäuse	Corps	Caja	Corpo
11	Table A	1			Housing Cover	Deckel	Couvercle	Cubierta	Coperchio
12	969	1			Adapter	Zwischenstück	Adaptateur	Adaptador	Adattatore
13	510	1			Ball Bearing	Kugellager	Roulement à billes	Cojinete de bolas	Cuscinetto a sfera
14	949	1			Spring Washer	Scheibe	Rondelle	Arandela	Rondella
15	979	1			Bearing Plate	Tragplatte	Plaque de support	Placa de asiento	Piattello cuscinetto
16	1354	2			Pin	Stift	Goupille cylindrique	Pasador	Spina
17	989	1			Cylinder	Zylinder	Cylindre	Cilindro	Cilindro
18	1343	3			Rotor Blade	Rotorblatt	Palette	Alabe del rotor	Paletta del rotore
19	982	1			Rotor	Rotor	Rotor	El rotor	Il rotore
20	977	1			Spacer	Distanzstück	Entretoise	Espaciador	Distanziale
21	978	1			Bearing Spacer	Lagerdistanzstück	Entretoise de coussinet	Separador de cojinetes	Distanziale cuscinetto
22	548	1			Ball Bearing	Kugellager	Roulement à billes	Cojinete de bolas	Cuscinetto a sfera
23	976	1			Chuck Body	Futter Körper	Corps de trou	Bote el Cuerpo	Il Corpo di ciottolo
24	Table A	1			Lock Nut	Überwurfmutter	Contre-ecrou molete	Tuerca de fijación	Dado di bloccaggio
25	Table A	1			Lock Ring	Verschlußring	Bague de verrouillage	Anillo de cierre	Anello di bloccaggio
26	Table A	1			Collet Guard	Schutzvorrichtung	Protection	Guarda	Protezione
27	100	1			Collet (1/8")	Futter	Douille de serrage	Boquilla	Bussola di chiusura
	102	1			Collet (3/32")	Futter	Douille de serrage	Boquilla	Bussola di chiusura
28	902	1			Guard Lock Ring	Verschlußring	Bague de verrouillage	Anillo de cierre	Anello di bloccaggio
29	901	1			Wedge	Keil	Cale	Cuña	Cuneo
30	913	1			O-Ring	O-Ring	Joint torique	Anillo “O”	Anello ad O
31	904	1			Lock Nut	Überwurfmutter	Contre-ecrou molete	Tuerca de fijación	Dado di bloccaggio
32	956	1		(1)	Wrenchless Chuck	Klammer	Serre-joint	La abrazadera	Il morsetto
	957	1		(1)	Wrenchless Chuck	Klammer	Serre-joint	La abrazadera	Il morsetto
	958	1		(1)	Wrenchless Chuck	Klammer	Serre-joint	La abrazadera	Il morsetto
Parts Not Shown:									
--	45-6003	1			Overhose	Schlauchabdeckung	Couverture de tuyau	Cubierta de la manguera	Copertura del tubo flessibile
--	45-0948	1			Intake Hose	Schlauch	Tuyau	Manguera	Tubo
--	14-0803	1		(2)	Wrench (3/16")	Schraubenschlüssel	Clé plate	La llave	La chiave
--	14-0822	1		(2)	Wrench (11/32")	Schraubenschlüssel	Clé plate	La llave	La chiave

(#) Quantity / Stückzahl / Quantité / Cantidad / Quantità
(1) Wrenchless Chuck capacities: 956 = 2.35mm, 957 = 3mm, 958 = 1/8"
(2) All models except 10R0412

Table "A"

Ref.	Description	Qty.	10N0400	Qty.	10N0401	Qty.	10R0400 10R0402	Qty.	10R0401	Qty.	10R0412
2	Adapter	1	971	1	971	1	01-0917	1	01-0917	1	01-0917
3	Set Screw	1	6063	1	6063	1	6057	1	6057	1	6057
10	Housing	1	972	1	972	1	972	1	972	1	952
11	Housing Cover		---		---		---		---		920
24	Lock Nut	1	970		---	1	970		---		---
25	Lock Ring		---	1	967		---	1	967	1	903
26	Collet Guard		---	1	1830		---	1	1830	1	905

COOPER Power Tools

Cooper Power Tools
P.O. Box 1410
Lexington, SC 29071-1410
USA
Toll Free: 800-845-5629
Fax: 803-359-0822
www.cooperpowertools.com